

7.5% Tax Change Guide

SPS-500 Series

Turn key to PGM or Program Mode

From Programming Menu touch Taxes

From Tax Programming screen touch the Type next to Tax #1

Select Tax Table

Maximum Non-Taxable Amount should be set to 0.09

First Tax Amount Charged should be set to 0.01

of Non-Repeat Breaks should be set to 2

of Repeat Breaks should be set to 15

Next you will enter the break points as followed:

0.13
0.26
0.40
0.53
0.66
0.80
0.93
1.06
1.20
1.33
1.46
1.60
1.73
1.86
2.09
2.13
2.26

Once all amounts are entered, touch Close

Test to make sure the calculation is correct by completing several test transactions.

10.00 should be .75 tax

100.00 should be 7.50 tax